Replacement Hardware Ordering Information

Hardware Part Numbers	
Valve Size	Part Number
1/4" through 1/2"	90108NBW
3/4"	91112NBW
1"	97116NBW
1-1/2"	97124NBW
2" and 2-1/2"	97132NBW
3" and 4"	97148NBW

^{*}Fits manual and pneumatically actuated bonnets.





Contact your sales representative for any non-standard hardware options.