

## Pneumatic Bonnet Ordering Information (Includes Hardware)



Size



Operation	Code
Normally Open	18
Normally Closed	19

Valve Configuration	Code
Standard (Four Blind Mounting Holes)	(Blank)
Zero-Static Tee, Point-of-Use, Block Valve	D4
SAL (Sterile Access Left)	L1

SAR (Sterile Access Right)

Valve

Configuration

## **Examples:**



N0819L 1/2" Valve | N/C Actuator | Standard Mounting Holes



N1619L1 1" Valve | N/C Actuator | SAL Mounting Holes



N0818D4 1/2" Valve | N/O Actuator | ZST Mounting Holes

Contact your sales representative for any non-standard bonnet options.